



KEMPER-KONTAKT Gert Kemper GmbH

Contact Wheels

Storage instruction for Contact Wheels

Contact wheels should never be stored one on the other or standing upright, because of mechanical pressure on the cushion will have bad influences on function of the wheel and void the warranty claim.

The contact wheels must be stored hanging with their centre hole on an mandrel. A horizontal storage is only for single wheels allowed, provided the core and cushion is even and will not under pressure. These instructions are valid generally, but absolutely necessary for contact wheels with foam cushion.

KEMPER-KONTAKT Gert Kemper GmbH

Siegersbusch 45a - D-42327 Wuppertal

Tel. +49 (0) 202 - 7 86 07-0

[E-Mail: kontakt@kemperkontakt.de](mailto:kontakt@kemperkontakt.de) - www.kemperkontakt.de